

# Wall & Ceiling Installation

## QUIET BATT™ Acoustic-Thermal Insulation

### Tools and Materials Needed

- Utility Knife
- Straight Edge
- Dust Mask or Respirator
- QUIET BATT™ Insulation Supports (if required)
- AMI Vapor Stop (if required)
- Staple Gun (if required)

### Step 1

#### Note:

Due to some compression during shipping we suggest shaking the material before installing to quickly rebound the properties of the insulation. We recommend installing AMI Vapor Stop for exterior wall applications. AMI Vapor Stop is to be installed towards the living space with a Staple Gun and Staples. Hang the Drywall or other sheeting material as soon as the Insulation is in place.

- 1) Take a measurement of the desired length. Place QUIET BATT™ Acoustic-Thermal Insulation on a flat, clean and dry surface. Transfer the measurements to the insulation.
- 2) Compress the Insulation with a Straight Edge and cut with a Utility Knife or simply tear with your hands.
- 3) QUIET BATT™ Acoustic - Thermal Insulation is a friction fit between 16 inch or 24 inch on center studs/ joists. **(A)**
- 4) To help support the Insulation between floor joists, use QUIET BATT™ Insulation Supports. **(B)**

